


- |   |  |  |   |  |  |
|---|--|--|---|--|--|
| <b>1 Information Brochure</b><br>Choose controls to match application | <b>2 Application Brochure</b><br>Design your mechanical applications | <b>3 Layout Brochure</b><br>Rough-in wiring instructions | <b>4 Wiring Brochure</b><br>Wiring and installation of specific control | <b>5 Data Brochure</b><br>Control settings and sequence of operation | <b>6 Job Record</b><br>Record settings & wiring details for future reference |
|---|--|--|---|--|--|

### Overview

The following brochure describes how to wire the tekmar tekmarNet®4 (tN4) thermostat 544. The 544 has outputs for: one heat stage, one cooling stage and one fan. The 544 has inputs for two auxiliary sensors. The wiring of 544 thermostat is simple and cost effective.



### Table of Contents:

Definitions.....	2	Electrical Drawings.....	3-7
Rough-In Wiring .....	2	Wiring the Thermostat .....	8-9
Remove the Wiring Cover .....	3	Troubleshooting the Wiring.....	10
Mounting the Thermostat .....	3	Testing the Wiring.....	11
Wiring Symbols.....	3	Technical Data.....	12

## Definitions

The following defined terms and symbols are used throughout this manual to bring attention to the presence of hazards of various risk levels, or to important information concerning the life of the product.



– Caution: Refer to accompanying documents.



– Caution: Refer to accompanying documents.

**INSTALLATION  
CATEGORY II**

– Local level appliances.

## ⚠ Caution ⚠

Improper installation and operation of this control could result in damage to the equipment and possibly even personal injury or death. It is your responsibility to ensure that this control is safely installed according to all applicable codes and standards. This electronic control is not intended for uses as a primary limit control. Other controls that are

intended and certified as safety limits must be placed into the control circuit. Do not attempt to service the control. Refer to qualified personnel for servicing. Apart from any field replaceable fuse(s) there are no user serviceable parts. Attempting to do so voids warranty and could result in damage to the equipment and possibly even personal injury or death.

## Rough-In Wiring

Choose the placement of the thermostats early in the construction process to enable proper wiring during rough-in.


Consider the following:

- Interior Wall
- Keep dry. Avoid potential leakage onto the control. RH ≤ 80% to 88°F (31°C), down to 50% from 104 to 122°F (40 to 50°C). Non-condensing environment.
- No exposure to extreme temperatures beyond 32- 122°F (0-50°C)
- No draft, direct sun, or other cause for inaccurate temperature readings.

- Away from equipment, appliances, or other sources of electrical interference.
- Easy access for wiring, viewing, and adjusting the display screen.
- Approximately 5 ft. (1.5 m) off the finished floor.

Use standard 18 AWG wire for the thermostat power, stages tN4 and sensor connections.

Refer to the diagram below to determine the number of conductors to run from each piece of equipment to the thermostat location.




**Note:** When multiple wires run to the same equipment location, wiring conductors can share one wire jacket.



## Remove the Wiring Cover:

To remove the wiring cover:


- Place a small slot screwdriver or similar tool into the slot located on the right side of the thermostat.
- While pushing against the plastic tab, lift off the wiring cover.



## Mounting the Thermostat

If a single or double gang switch box is used, mount the thermostat directly to the box.


- Feed the wiring through the openings in the back of the thermostat.
- Use the upper and lower screw holes to fasten the thermostat to the box.



If a switch box was not used, mount the thermostat directly to the wall.

- Feed the wiring through the openings in the back of the thermostat.
- Use screws in the upper and lower screw holes to fasten the thermostat to the wall. At least one of the screws should enter a wall stud or similar rigid material.

OR



## Wiring Symbols

	Dry contact switch. Operates a device.	<b>Do Not Apply Power</b>	<b>Do not apply power</b> to these terminals. Serious control damage will result.
	Powered switch. 24 V (ac), switched output to valve, pump relay etc.		tekmarNet®4
	Factory jumper.		

## ⚠ Electrical Drawings

⚠ The electrical drawing examples on the following pages show the 544 in common applications. Choose the drawing that most accurately depicts the components in your system and use that drawing as a guide to aid in wiring your system.

These are only concept drawings, not engineered drawings. They are not intended to describe a complete system nor any particular system. It is up to the system designer to


determine the necessary components for and configuration of the particular system being designed including additional equipment isolation relays (for loads greater than the controls specified output ratings) and any safety devices which in the judgement of the designer are appropriate in order to properly size, configure and design that system and to ensure compliance with building and safety code requirements.

**Description:**

One Stage Heating (H1 = Radiant), One Stage Cooling (C1 = Compressor), One Speed Fan (F1 = C1), Fan Mode = 1.

**Legend:**

Sensor 1 = Floor  
 Sensor 2 = Outdoor




**Description:**

One Stage Heating (H1 = Radiant), One Stage Cooling (C1 = Compressor & Fan), One Ventilation Fan (F1 = Vent), Fan Mode = None.

**Legend:**

Sensor 1 = Room  
Sensor 2 = Floor




**Description:**

One Stage Heating (H1 = Coil), One Stage Cooling (C1 = Coil), One Speed Fan (F1 = H1 & C1), Fan Mode=2.

**Legend:**

Sensor 1 = Remote

Sensor 2 = Room




**Description:**

One Stage Heating (H1 =Furnace), One Stage Cooling (C1 =Compressor), One Speed Fan (F1 =H1 & C1), Fan Mode=2.

**Legend:**

Sensor 1 = Remote

Sensor 2 = Outdoor



## Wiring the Thermostat:

### ⚠ Power (24 V (ac))

Terminals 9, 10


Wire 24 V (ac) to terminals C and R.

If a Zone Manager is used:

- Connect C on the thermostat to C on the proper zone of the Zone Manager.
- Connect R on the thermostat to R on the proper zone of the Zone Manager.

If a 24 V (ac) transformer is used:

- Connect C on the thermostat to C on the transformer.
- Connect R on the thermostat to R on the transformer.



### ⚠ tN4 Communication

Terminals 8, 9


Wire the tN4 communication to terminals tN4 and C.

If a Zone Manager is used:

- Connect the tN4 on the thermostat to the tN4 on the proper zone of the Zone Manager used for the first stage of heat. The C terminal is already connected.

If a Zone Manager is not used:

- Connect the tN4 on the thermostat to the tN4 on another tN4 device on the same tN4 bus.
- Connect the C on the thermostat to the C terminal on another tN4 device on the same tN4 bus.



**Note:** This connection is polarity sensitive.

### ⚠ Heat 1 Relay

Terminals 11, 12

Wire the first stage of heating to the Heat 1 Relay. (Rh1 - W1)


- Use these terminals as a switch to operate the first stage of heating.

If a Zone Manager is used:

- Connect W1 on the thermostat to W on the proper zone of the Zone Manager.

If a Zone Manger is not used:

- Determine if the factory jumper must be cut.
- When the factory jumper is not cut, W1 is a powered output that is internally connected to R.
- When the factory jumper is cut, Rh1-W1 is an isolated switch. No power is available from these terminals.




### ⚠ Cool 1 Relay

Terminals 3, 4

Wire the first stage of cooling to the Cool 1 Relay. (Rc - Y1)

- Rc - Y1 is an isolated switch. No power is available from these terminals
- Use these terminals as a switch to operate the first stage of cooling.






## ⚠ Fan 1 Relay

Terminals 1, 2, 3

Wire the first stage of fan to the Fan 1 Relay. (G1 - G1)

- G1 - G1 is an isolated switch. No power is available from these terminals.
- Use these terminals as a switch to operate the first stage of fan.




## ⚠ Auxiliary Sensors

Terminals 5 - 7

The auxiliary sensors are connected to the thermostat on terminals Com, S1 and S2.

- Connect sensor 1 to terminals S1 and Com.
- Connect sensor 2 to terminals S2 and Com.

**Do not apply power** to terminals 5-7, permanent damage to the sensors and/or thermostat will result!




Do Not Apply Power

## Troubleshooting the Wiring

### **General**

The following tests are to be performed using standard testing practices and procedures and should only be carried out by properly trained and experienced persons.

A good quality electrical test meter, capable of reading from at least 0-300 V (ac), 0-2,000,000 Ohms, and testing for continuity is essential to properly test the wiring and sensors.




## Testing the Wiring

### ⚠ Testing 24 V (ac) Power Supply

1. Remove the front cover from the thermostat.
2. Use an electrical test meter to measure (ac) voltage between the R and C terminals. The reading should be 24 V (ac)  $\pm$  10%.
3. Install the front cover.

### ⚠ Testing the Relays

1. Remove the front cover from the thermostat.
2. Disconnect the wires from the relay that is to be tested.
3. Use an electrical test meter and check for continuity across the relay.
  - When the relay's symbol is displayed in the LCD, there should be continuity.
  - When the relay's symbol is not displayed in the LCD, there should be no continuity.
4. Reconnect the wires to the relay.
5. Repeat steps 2 to 4 for each relay that is to be tested.
6. Install the front cover on the thermostat.



### ⚠ Testing the Sensors

To test the sensors, the actual temperature at each sensor location must be measured.

Use a good quality digital thermometer with a surface temperature probe for ease of use and accuracy. Where a digital thermometer is not available, place a spare sensor alongside the one to be tested and compare the readings.

1. Remove the front cover from the thermostat.
2. Disconnect the wires from the sensor that is to be tested.
3. Test the sensor's resistance according to the instructions in the sensor Data Brochure D 070, D 074 or D 079.
4. Reconnect the wires.
5. Install the front cover on the thermostat.

### ⚠ Testing the tN4 Network

To test the tN4 Network, check the wires for continuity.

1. Remove the front cover from the thermostat.
2. Disconnect the two wires (tN4 and C) at one end and connect them together.
3. Go to the other end of the wires and disconnect them.
4. Using an electrical test meter, check for continuity.
5. Reconnect the wires.
6. Install the front cover on the thermostat.

## Technical Data

### tekmarNet<sup>®</sup>4 Thermostat 544: *One Stage Heat, One Stage Cool, One Fan*

Control	Microprocessor PID control; This is <b>not a safety (limit) control</b>
Packaged weight	1.05 lb. (476 g)
Enclosure	White PVC plastic
Dimensions	4-1/2" H x 4-3/4" W x 7/8" D (114 x 120 x 22 mm)
Approvals	CSA C US, CSA/UL 61010-1, meets Class B: ICES and FCC Part 15
Ambient conditions	Indoor use only, 32 to 122°F (0 to 50°C)
	RH ≤ 80% to 88°F (31°C), down to 50% from 104 to 122°F (40 to 50°C)
	Altitude <6560 feet (2000 m), Installation Category II, Pollution Degree 2
Power supply	24 V (ac) ± 10% 60 Hz, 1.5 VA, NEC / CEC Class 2
W1 Relay	24 V (ac) 2 A
Y1 Relay	24 V (ac) 2 A
G1 Relay	24 V (ac) 2 A
Sensors:	NTC thermistor, 10 kΩ @ 77°F (25°C ± 0.2°C) β = 3892
– Included	None
– Optional	tekmar type # 070, 071, 072, 073, 076, 077, 078, 079, 082, 084

The installer must ensure that this control and its wiring are isolated and/or shielded from strong sources of electromagnetic noise. Conversely, this Class B digital apparatus complies with Part 15 of the FCC Rules and meets all requirements of the Canadian Interference-Causing Equipment Regulations. However, if this control does cause harmful interference to radio or television reception, which is determined by turning the control off and on, the user is encouraged to try to correct the interference by re-orientating or relocating the receiving antenna, relocating the receiver with respect to this control, and/or connecting the control to a different circuit from that to which the receiver is connected.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.



tekmar Control Systems Ltd., Canada  
 tekmar Control Systems, Inc., U.S.A.  
**Head Office: 5100 Silver Star Road**  
**Vernon, B.C. Canada V1B 3K4**  
**(250) 545-7749 Fax. (250) 545-0650**  
**Web Site: [www.tekmarcontrols.com](http://www.tekmarcontrols.com)**