Series 009, LF009, LF009-FS

Second Check Module Assembly

Test Cock

Redu	iced Press	ure Zone Assemblies
Sizes	2 ¹ / ₂ " – 3"	
Repair	r Kits	
•		g Code, Kit No., and Valve Size.
ORDERIN		SIZE
CODE	a KITNO.	SILL
Total R	epair Kits»	
0794051	LFRK 009-T	2 1/2" – 3"
Kit consists (if plastic)	of: relief valve repair kit,	first check repair kit, second check repair kit, retainer
Relief	Valve Kits	
Total R	elief Valve Kit»	
0794052	LFRK 009 VT	2 1/2" – 3"
Kit consists O-ring.	s of: seat, stem assembly, s	spring, two piston O-rings, flow tube O-ring and cove
	/alve Rubber Par	
0794053		2 1/2" – 3"
cover O-rin Stem O-rin	g. g located between stem a	ed disc assembly, piston 0-ring, stem 0-ring and nd piston 0-ring.
Check	Valve Kits	
When orc	lering specify Orderin	g Code, Kit No., and Valve Size.
ORDERING CODE	G KIT NO.	SIZE
First C	heck Parts Kit»	
0794054	LFRK 009 CK1	2 1/2" – 3"
Secon	d Check Parts Ki	t»
₽ 0794055	LFRK 009 CK2	2 1/2" – 3"
Kit consists	of: check assembly, cove	r O-ring and flow tube O-ring.
First C	heck Rubber Par	ts Kit
0887281	RK 009 RC1	2 1/2" – 3"
Secon	d Check Rubber	Parts Kit
0887205	RK 009 RC2	2 1/2" – 3"
Kit consists	of: disc, seat O-ring, cove	r O-ring and flow tube O-ring.
	ubber Parts	
₽ 0794056	LFRK 009 RT	2 1/2" – 3"
	piston O-rings, RV stem C	ed disc assemblies, two seat 0-rings, RV I-ring, flow tube 0-ring and cover 0-ring.
		2 1/2" – 3"
	of: cover, cover O-ring an	
	Seat Kit	a now tube o mily.
0007000		2 1/2" – 3"
0887209		2 1/2" - 3"
Kit consists	of: check seat, seat O-rin	g and cover O-ring.
Sensor	Kits	
ORDERING CODE		DESCRIPTION
		r LF009-FS sizes 2½" – 3"
88003056		BMS Sensor Connection Kit
88003060		Cellular Sensor Connection Kit
Sensor		n Kits for LF009-FS sizes 2½" – 3" BMS Sensor Retrofit Connection Kit
88003059		

Test Cock… No. 3 Test No. 2 Cock No. 4 First Check Module **R.P. Zone** ¢ Assembly Relief Valve Assembly Water Outlet Flow Tube 0-ring Cover O-ring Piston 0-ring Diaphragm **RV 0-ring** • Relief Valve Service Parts Kit Disc Stem Assembly Stem 0-ring Stem Assembly Disc* Retainer Spring Seat Seat 0-ring **Check Assemblies** Seat Seat O-ring Spring Cage/Seat -Rominio Disc* Assembly **Spring Guide** Cover Cover O-ring Flow Tube . Second Ch Service Parts (b) and Flow Tube O-ring A riist uneur Kit Service Parts Kit Retainer 10 0 mar Body .

Rubber seat disc can be replaced. However, disc holder and disc retainer are permanently bonded to prevent failure.

*The wetted surface of this product contacted by consumable water contains less than 0.25% of lead by weight.

Cellular Sensor Retrofit Connection Kit

88003063 FP-RFK-BF-CFS

First and Second Check Valve modules are not interchangeable.