

Rainwater Harvesting - Accessories

Job Name _____
 Job Location _____
 Engineer _____
 Approval _____

Contractor _____
 Approval _____
 Contractor's P.O. No. _____
 Representative _____

RWA-LVL

Submersible Level Transmitter

Submersible level transmitters are sensors designed to detect the height of water levels inside a storage tank. The transmitter outputs a 4-20mA analog signal that can be interpreted by control systems to determine water level.

Features

- 316L Stainless Steel Construction
- Industry standard 4-20mA analog output
- 16-bit internal digital error correction for low Total Error Band (TEB)₃
- Integrated lightning protection
- Manufactured by Keller America®



RWF-LVL

Available Models

MODEL	SENSOR RANGE (FT)	CABLE LENGTH (FT)	OUTPUT	PROTECTION RATING	SENSOR LENGTH (IN)	SENSOR WIDTH (IN)
RWA-LVL15-20	15	20	2-wire (mA)	IP68	4.52	0.825
RWA-LVL-40-50	40	50	2-wire (mA)	IP68	4.52	0.825

NOTICE

The information contained herein is not intended to replace the full product installation and safety information available or the experience of a trained product installer. You are required to thoroughly read all installation instructions and product safety information before beginning the installation of this product.

Watts product specifications in U.S. customary units and metric are approximate and are provided for reference only. For precise measurements, please contact Watts Technical Service. Watts reserves the right to change or modify product design, construction, specifications, or materials without prior notice and without incurring any obligation to make such changes and modifications on Watts products previously or subsequently sold.

WARNING

Rainwater supplied by Watts rainwater harvesting systems is not potable water and is not intended for potable water applications. Do Not Drink Water supplied from Watts rainwater systems and related equipment. Users shall determine the suitability of the product for the intended application before using.



USA: T: (800) 659-8400 • F: (800) 659-8402 • Watts.com

Canada: T: (905) 332-4090 • F: (905) 332-7068 • Watts.ca

Latin America: T: (52) 81-1001-8600 • F: (52) 81-8000-7091 • Watts.com